



Water Filter Installation Instructions

Follow these simple instructions for your filter type.



Refrigerator Water Filter 7

■ Part UKF7003



1. Locate the filter head; in the upper right hand side of the refrigerator compartment or in the machine compartment on built in refrigerator models.
2. During initial installation of the water filter, remove the bypass cap by a ¼ turn counter clockwise, retain for later use. During replacement installation rotate the used filter counter clockwise until it is released from the filter head. Twist gently and do not pull. Note: there may be some water in the filter and some spilling may occur.
3. Remove the new filter from the packaging. Remove the filter cap.
4. Lubricate the O-ring with food grade vegetable oil.
5. Line up the cartridge ears so it can be inserted into the filter head. Rotate the filter cartridge ¼ turn clockwise.
6. Reduce water spurts by flushing air from the system. Run water continuously for 4 gallons (approximately 5 minutes) through the dispenser until water runs steady. Additional flushing may be required in some households where water is of poor quality.

www.waterfilterforfridge.com.au